



TOOL

**Baker Style
C-1 Running Tool**



**WESTERN PRESSURE
CONTROLS 2005 LTD.**
10021-56TH AVENUE
EDMONTON, AB, CA
PH: (780) 437-3615
FX: (780) 437-3616

www.westernpressure.com

WESTERN PRESSURE CONTROLS 2005 LTD.

#	PART NAME	1.500"	2.000"	2.500"
	ASSEMBLY	R1.500C100	R2.000C100	R2.500C100
1	BODY	R1.500C101	R2.000C101	R2.500C101
2	C-1 RING	R1.500C102 (1.468")	R2.000C102 (1.807")	R2.500C102 (2.281")
	"	R1.500C103 (1.520")	R2.000C103 (1.843")	R2.500C103 (2.343")
	"	R1.500C104 (1.593")	R2.000C104 (1.906")	--
	"	R1.500C105 (1.656")	--	--
3	SET SCREW	1/4-20UN	1/4-20UN	5/16-18UN

#	3.000"	4.000"
	R3.000C100	R4.000C100
1	R3.000C101	R4.000C101
2	R3.000C102 (2.781")	R4.000C102 (3.717")
2	R3.000C103 (2.843")	R4.000C103 (3.835")
3	1/4-20UN	1/4-20UN

PURPOSE:

To run Baker style Plugs and Chokes down the wellbore

SPECIFICATIONS:

C-1 Ring outside diameters are given in part number chart.

TOOL

**Baker Style
C-1 Running Tool**



**WESTERN PRESSURE
CONTROLS 2005 LTD.**
10021-56TH AVENUE
EDMONTON, AB, CA
PH: (780) 437-3615
FX: (780) 437-3616

www.westernpressure.com