



TOOL

**ROPE SOCKET
WEDGE AND SLEEVE**



**WESTERN PRESSURE
CONTROLS 2005 LTD.**
10021-56TH AVENUE
EDMONTON, AB, CA
PH: (780) 437-3615
FX: (780) 437-3616

www.westernpressure.com

WESTERN PRESSURE CONTROLS 2005 LTD.

#	PART NAME	0.750"	1.000"	1.250"	1.500"
	ASSEMBLY	S0.750WRS00	S1.000WRS00	S1.250WRS00	S1.500WRS00
1	BODY	S0.750RS03	S1.000RS01	S1.250RS01	S1.500RS07
2	SLEEVE	S1.000RS06	S1.000RS06	S1.000RS06	S1.500RS05
3	0.108/0.125 WEDGE	S1.500RS06	S1.500RS06	S1.500RS06	S1.500RS06
3	0.143 WEDGE	S1.500RS15	S1.500RS15	S1.500RS15	S1.500RS15
4	BOTTOM SUB	S0.750WRS05	S1.000RS05	--	--

#	1.750"	2.000"	2.125"
	S1.750WRS00	S2.000WRS00	S2.125WRS00
1	S1.750RS02	S2.000RS01	S2.125RS01
2	S1.500RS05	S1.500RS05	S1.500RS05
3	S1.500RS06	S1.500RS06	S1.500RS06
3	S1.500RS15	S1.500RS15	S1.500RS15



PURPOSE:

To securely tie in the wireline to the toolstring.

SPECIFICATIONS:

Only the 3/4" and the 1" assemblies have bottom subs.

TOOL

**ROPE SOCKET
WEDGE AND SLEEVE**



**WESTERN PRESSURE
CONTROLS 2005 LTD.**
10021-56TH AVENUE
EDMONTON, AB, CA
PH: (780) 437-3615
FX: (780) 437-3616

www.westernpressure.com