



TOOL

## CLAMP STYLE ROPE SOCKET



**WESTERN PRESSURE  
CONTROLS 2005 LTD.**  
10021-56TH AVENUE  
EDMONTON, AB, CA  
PH: (780) 437-3615  
FX: (780) 437-3616

[www.westernpressure.com](http://www.westernpressure.com)

# WESTERN PRESSURE CONTROLS 2005 LTD.

#	PART NAME	1.500"	1.750"	3.000"
	ASSEMBLY	S1.500RSL00	S1.750RSL00	S3.000RSL00
1	TOP SUB	S1.500RSL01	S1.750RSL01	S3.000RSL01
2	END RETAINER (0.188 LINE)	S1.500RSL05	S1.500RSL05	S1.500RSL05
2	END RETAINER (0.140, 0.150, 0.160 LINE)	S1.500RSL08	S1.500RSL08	S1.500RSL08
3	CLAMP BODY (0.188 LINE)	S1.500RSL03	S1.500RSL03	S1.500RSL03
3	CLAMP BODY (0.140, 0.150, 0.160 LINE)	S1.500RSL06	S1.500RSL06	S1.500RSL06
4	MIDDLE RETAINER (0.188 LINE)	S1.500RSL04	S1.500RSL04	S1.500RSL04
4	MIDDLE RETAINER (0.140, 0.150, 0.160 LINE)	S1.500RSL07	S1.500RSL07	S1.500RSL07
5	BOTTOM SUB	S1.500RSL02	S1.750RSL02	S3.000RSL02
6	SCREW	1/4-20UN	1/4-20UN	1/4-20UN

**PURPOSE:**

To securely tie in the wireline to the toolstring.

TOOL

**CLAMP STYLE ROPE SOCKET**



**WESTERN PRESSURE  
CONTROLS 2005 LTD.**  
10021-56TH AVENUE  
EDMONTON, AB, CA  
PH: (780) 437-3615  
FX: (780) 437-3616

[www.westernpressure.com](http://www.westernpressure.com)