



TOOL

J-UNLATCHING TOOL



**WESTERN PRESSURE
CONTROLS 2005 LTD.**
10021-56TH AVENUE
EDMONTON, AB, CA
PH: (780) 437-3615
FX: (780) 437-3616

www.westernpressure.com

WESTERN PRESSURE CONTROLS 2005 LTD.

#	PART NAME	3/4"	1"	1 3/16"	1 3/8"	3"
	ASSEMBLY	B0.750JUT00	B1.000JUT00	B1.188JUT00	B1.375JUT00	B3.000JUT00
1	TOP SUB	B0.750JUT01	B1.000JUT01	B1.188JUT01	B1.375JUT01	B3.000JUT01
2	BODY	**	**	B1.188JUT02	B1.375JUT02	B3.000JUT02
3	SPRING	B0.750JUT03	B1.000JUT03	B1.188JUT03	B1.375JUT03	B3.000JUT03
4	PISTON	B0.750JUT04	B1.000JUT04	B1.188JUT04	B1.375JUT04	B3.000JUT04
5	GUIDE PIN	0.25	0.25	0.25	0.25	0.25
6	SET SCREW	1/4-20UN	1/4-20UN	1/4-20UN	1/4-20UN	5/16-18UN
	J-HEAD FISHNECK	0.750	1.000	1.188	1.375	2.313
	MAX O.D.	1.031	1.281	1.500	1.720	2.740

** INDICATES TOP SUB AND BODY ARE ONE PIECE

WPC

PURPOSE:

Designed to set instrumentation into well bore in conjunction with WPC 'J' unlatch head fishneck, at pre-determined depth without having to jar to release

TOOL

J-UNLATCHING TOOL



WESTERN PRESSURE CONTROLS 2005 LTD.
 10021-56TH AVENUE
 EDMONTON, AB, CA
 PH: (780) 437-3615
 FX: (780) 437-3616

www.westernpressure.com